

Rock Island PH1 Modernization Project Remedial Waterstop Project Bid 05-06



Waterstop Installation Steps

- ▶ Drill Hole
- ▶ Insert sleeve
- ▶ Fill sleeve with waterstop material

Drilling



Drilling



Sleeve Insertion



Sleeve Insertion



Filling Sleeve

